




Locations

CAUTION: After installing the rocker shaft orifice, try to turn the rocker shaft to make sure that the orifice has been inserted in the hole of the rocker shaft correctly- If the orifice is in place, it should not turn.

NOTE:

- Identify parts as they are removed to ensure reinstallation in original locations.
- Inspect rocker shafts and rocker arms (see pages 6-32 ('91-'93) or ('94-'96) and 33 ('91-'93) or ('94-'96) .
- Rocker arms must be installed in the same position if reused.
- Adjust the rocker arms after torquing the cylinder head bolts.

 Prior to reinstalling, clean all the parts in solvent, dry them, and apply lubricant to any contact surfaces.

