

# Gearshift Mechanism

## Overhaul

**NOTE:**

- Inspect rubber parts for wear and damage when disassembling.
- Check that the new cotter pin is seated firmly.

