



# Cruise Control

## Component Location Index

SRS components are located in this area. Review the SRS component locations, precautions, and procedures in the SRS [section \(24\)](#) before performing repairs or service.





VEHICLE SPEED SENSOR (VSS)  
Test, page [23-131](#) ('94-'96) ('91-'93)

