



# Rocker Arms and Shafts

## Locations

**CAUTION:** After installing the rocker shaft orifice, try to turn the rocker shaft to make sure that the orifice has been inserted in the hole of the rocker shaft correctly. If the orifice is in place, it should not turn.

**NOTE:**

- Identify parts as they are removed to ensure reinstallation in original locations.
- Inspect rocker shafts and rocker arms (pages 6-36 and 37).
- Rocker arms must be installed in the same position if reused.
- Install the rocker arms after torquing the cylinder head bolts.



Prior to reinstalling, clean all the parts in solvent, dry them and apply lubricant to any contact surfaces.

