






# Component Locations

## Index



**PGM-FI MAIN RELAY**  
Relay Testing, page 11-120  
Troubleshooting, page 11-122





**SERVICE CHECK CONNECTOR (2P)**  
Self-diagnostic Procedures, page 11-34

**ENGINE CONTROL MODULE (ECM)**  
Self-diagnostic Procedures, page 11-34  
Troubleshooting, page 11-42

# Component Locations

## Index

---



**FUEL PUMP RELAY**  
Troubleshooting, page 11-116

