


Headlights

Adjustment

Adjust the headlights to local requirements by turning the adjusters as shown.

NOTE: Be careful not to damage the front fender or the headlight housing when adjusting.



HEADLIGHT HORIZONTAL AIM ADJUSTER

PROTECTIVE TAPE

HEADLIGHT VERTICAL AIM ADJUSTER