Roof

Index


ROOF
REAR RECEIVER DAMPER
SHIM
REAR RECEIVER SWITCH
HOOK STOP
(see page 20-94)
ROOF SIDE HOOK
ROOF SIDE LOCK
Replacement, page 20-83
SIDE LOCK RELEASE KNOB
REAR LOCK RECEIVER
Replacement, page 20-92
Adjustment, page 20-92
ROOF LOCK GUIDE
Replacement, page 20-90
SHIM
ROOF LOCK GUIDE
Replacement, page 20-90
REAR ROOF STOP GUIDE
Replacement, page 20-91
ROOF SIDE RETAINER
Replacement, page 20-84
FRONT LOCK RECEIVER
Replacement, page 20-92
Adjustment, page 20-92
ROOF SIDE LOCK HANDLE
ROOF SIDE LOCK UNIT
Replacement, page 20-89
Adjustment, page 20-106
REAR ROOF HOLDER
SHIM
ROOF TRIM PANEL
(see page 20-83)
RIGHT ROOF SIDE TRIM
(see page 20-82)
ROOF SIDE SEAL
Replacement, page 20-84
ROOF GRIP
ROOF FRONT TRIM
(see page 20-82)
LEFT ROOF SIDE TRIM
(see page 20-82)